

# THANK YOU FOR YOUR NEW SOLVING PRODUCTS PURCHASE



## CONTACT SOLVING PRODUCTS LLC

Phone..... (855) 661-9124  
Email..... Help@SolvingProducts.com  
Website..... www.SolvingProducts.com



### IMPORTANT SAFETY NOTE

When using an electric product, basic precautions should always be followed. To reduce the risk of electric shock: The power plug and the accessories connected to it are not for immersion or for use in shower. Do not use an extension cord with this product. Unplug and remove power cord before cleaning. The batteries used in this product may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 100°C (212°F) or incinerate. To reduce the risk of burns, fire, electric shock, or injury to persons: Close supervision is required when this product is used by, on, or near children, or persons with limited physical, sensory, or mental capabilities or invalids. Use this product only for its intended household use as described in this manual. Do not use attachments not recommended by Philips North America LLC. Never operate this product if it has a damaged power cord or charging plug, if it is not working properly, if it has been dropped or damaged, or dropped into water while plugged in. Keep the cord and power plug dry at all times. Do not handle with wet hands. Only use the power plug, USB plug and other accessories supplied with the product.

# UNBOXED ADVANTAGE

### WHAT IS UNBOXED?

Solving Products LLC offers brand-new products direct from manufacturer for consumers at low economical prices. Shipped in smaller, environmentally responsible packaging to reduce waste are only a few cost saving methods used to create the Unboxed Advantage.

- > Customer oriented with exceptionally low consumer pricing
- > Streamlined package reduces waste resulting in low environmental impact
- > 1-Year extended service plan provided by Solving Products LLC
- > Customer support available over the phone or visit our website

### CUSTOMER SUPPORT

Solving Products customer support team is knowledgeable and ready to help. Available weekdays and weekends 24/7 by phone.

PLEASE DO NOT CONTACT ORIGINAL MANUFACTURER DIRECTLY

Phone..... (855) 661-9124  
Email..... Help@SolvingProducts.com  
Website..... www.SolvingProducts.com

### EXTENDED SERVICE PLAN

Purchases are backed by 1-year extended service plan ensuring products will be free from defects in material and workmanship for one year from date of purchase. Solving Products LLC will repair or replace product free of charge during this year. Consumable components (for example, shaver heads) are excluded in this plan. Service does not cover equipment failure attributed to accident, improper operation, misuse, abuse, or any cause other than defects in the materials or workmanship.



IMPORTANT: PLEASE CHARGE COMPLETELY BEFORE FIRST USE

# UNBOXED

## NEW S9721

## ELECTRIC WET & DRY SHAVER OPERATION GUIDE AND EXTENDED SERVICE PLAN

NEW ITEM WAS CAREFULLY PACKAGED BY SOLVING PRODUCTS, LLC, CERTIFIED RETAIL PARTNER OF PHILIPS NORELCO



## OPERATION GUIDE

- Operation Overview
- System Display
- Click-on Attachments
- Supplied With
- Contact and Safety Notice
- Unboxed Advantage Explained

# OPERATION OVERVIEW

Buttons explained for new Philips Norelco S9721 shaver.

## CHARGING & POWER

To prolong shaver lifespan charge before first use and only when indicated. Power shaver on or off by pressing on/off button once.

1. Power shaver off by pressing on/off button once
2. Connect shaver to supplied AC charger only and any 100V-240V AC outlet
3. Shaver display will indicate battery is charging by flashing white
4. Unplug shaver when charge indicator is illuminated with continuous white light



# SYSTEM DISPLAY

## BATTERY CHARGE INDICATOR

A. Charging	Percentage and icon flash white while charging
B. Full Charge	Percentage lights up white continuously
C. Battery Low	Charge indicator flashes orange, shaver beeps
D. Remaining Charge	Indicated by battery charger percentage

## MESSAGES & FUNCTIONALITY



### Over Heating & Blocked Shaving Heads

If shaver overheats during charging or becomes clogged while in use, exclamation mark flashes orange, charging/use continues when temperature decreases or shaver is cleaned



### Cleaning Reminder

Clean shaver after every shave for optimal performance, symbol flashes when shaver is turned off



### Replace Shaving Head (Replacement Part # SH90)

Shaving unit symbol lights up and arrows flash to indicate replacement of shaving head - reset the replacement reminder by pressing the on/off button for 7 seconds




### Travel Lock On/Off

Press the on/off button for 3 seconds to activate or deactivate lock mode which prevents accidental power when traveling

# CLICK-ON ATTACHMENTS

## USING CLICK-ON ATTACHMENTS

1. Make sure the product is switched off
2. Pull attachment straight off shaver, do not twist
3. Insert lug of new attachment into slot on top of shaver, then press down to attach (listen for click)



# AVAILABLE ACCESSORIES

NOTE: THE ACCESSORIES SUPPLIED MAY VARY FOR DIFFERENT PRODUCTS. THE PACKAGE SHOWS ACCESSORIES THAT HAVE BEEN SUPPLIED WITH YOUR PRODUCT.

S9721 Shaver, click-on trimmer, cleaning station, case, AC charger, operation guide, plus 1 year extended service.

